



**MINI-MADNESS.COM**

### **Madness Locking Header Bolt Installation**

**Tools needed: 10mm socket and 11mm socket**

- 1. Remove the factory 10mm header bolts. Remove and install only one bolt at a time if you are just replacing the bolts and not the entire header system**
- 2. Install the new 11mm locking bolts and tighten to 24nm or 18ft lb.**
- 3. Place red locking teardrop's on the bolts and snap on circlip as show in photo below.**

**NOTE: Make sure the red teardrops are placed correctly to prevent bolt back out.**

